

AVERY/MARLO/WYATT BEDS

Recommended Tools/Materials

- Hex screwdriver
- Socket set (½" socket or Ratcheting Wrench ½")

This Product Includes

- Headboard with 6 1-inch hex head bolts (3 on each side)
- Footboard with 6 1-inch hex head bolts (3 on each side)
- 2 side rails with 8 1-inch hex head bolts (4 on each rail)
- Steel support slats
- 4 L-brackets (2 attached to each side rail)

Installation Instructions

Note: We recommend assembling this item with a friend.

1 Stand the headboard upright. Halfway unscrew the 6 hex head bolts on the headboard (3 on each side) to give enough room to slide the bracket on (see step 2).

2 Slide one side rail up onto the headboard so the L-bracket connects to all 3 bolts. Tighten the 3 hex head bolts onto the L-bracket.

3 Repeat step 2 on the other side of the bed.

4 Keeping the headboard and side rail assembly upright, attach the footboard to the side rails in the same way you attached the headboard.

5 Add the metal slats across the bed with their flat side facing up.

6 Place your mattress on the slats.