Berkeley Bed Assembly Instructions

List of parts:

- 1 headboard
- 1 footboard
- 2 side rails
- 10 steel slats (Twin/Full); 12 steel slats (Queen/King/California King)
- 4 threaded rods
- 4 nuts
- 4 curved washers
- 4 chair nails
- 8 dowels

Tools needed:

wrench (included)

Directions:

- 1. Position headboard upright, near desired placement location.
- 2. With front of headboard facing you, screw threaded rods into inserts, located on the legs of the headboard and footboard. (Figure 1)
- 3. Place dowels in pre-drilled holes. Align dowels and rod with holes on side rail and push together. (Figure 2)
- 4. Slide curved washer and nut on threaded rod and tighten with wrench. (Figure 3)
- 5. Repeat steps 2 through 4 for second side rail.
- 6. Attach footboard to both side rails in same manner as headboard.
- 7. Place slats on side rails, matching the slots in each slat to the rivet on the side rails.
- 8. Place mattress on slats.







Figure 2

Figure 3



Figure I