

Campo Bed Assembly Instructions

Lists of parts: 1 top short rail (with hole to receive bolts & 2 wood bullets)
1 bottom short rail (with hole to receive bolts & 2 wood bullets)
2 side long rails (with metal insert)
10 wood slats

Hardware: 4-3 7/8 inch threaded stud
4- nuts
4- curved washer
8- screws

Tools: Wrench (provided)
Screw driver



Directions:

1. Take the 2 side long rails and screw the 3 7/8" threaded stud into the insert until it stops. Put the nut 3 to 6 turns onto the end of the threaded stud. Take 1 of the side rails and connect to the top short rail.
2. Slide the top short rail over the nut and into the mating holes for the bullets on the side long rail.
3. Slide the curved washer into the large hole, with the curve of the washer against the curve of the round hole. Tighten the nut with wrench (provided).
4. Slide the bottom short rail over the nut and into the mating holes for the bullets on the side long rail.
5. Slide the curved washer into the large hole, with the curve of the washer against the curve of the round hole. Tighten the nut with wrench (provided).
6. Take the other side long rail and assemble to the top short rail and bottom short rail in the same manner.
7. At this point, the bed is free standing. With a screwdriver, install the 2 screws per corner bracket into the corner metal bracket (Corner metal bracket is pre-attached to the top short rail and bottom short rail).
8. Insert the 10 wood slats into the slots provided in the side long rails.