

Moda Full Length Guard Rail Assembly Instructions

List of parts: 1 - full length guardrail with mounting brackets attached

Hardware: 4 - screws

Tools needed: Phillips screwdriver

- Directions:**
1. Unscrew and remove existing guard rail mounting brackets from both ends of guard rail. **This step needs to be done only with full length guard rail** to prevent headboard from interfering with installation.
 2. Insert guard rail onto bed rail. Once rail is in proper position replace both guard rail mounting brackets, facing inside of bed rail. Finally, secure guard rail to side rail with two screws in each bracket.

