

ARCHITECTURE BED

Recommended Tools/Materials

- Phillips screwdriver
- Rubber mallet

This Product Includes

- Headboard
- Footboard
- 2 side rails
- 2 canopy top rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/California King)
- 4 screws

Installation Instructions

Note: We recommend assembling this item with a friend. When disassembling, use rubber mallet to remove side rail tab from metal pocket.

- 1 Hold headboard upright near its desired placement, with metal pockets facing the center of the bed.
- 2 With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard. Repeat for other side.
- 3 Attach footboard to both rails in the same manner as headboard.
- 4 Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.
- 5 Place canopy rails with tabs upright on top of bed posts. Push headboard and foot board together.
- 6 Secure the rails with the screws.
- 7 Place your mattress on the slats.