

ARCHITECTURE BED WITH FABRIC HEADBOARD

Recommended Tools/Materials

- Phillips screwdriver
- Rubber mallet

This Product Includes

- Headboard
- Headboard panel
- Footboard
- 2 side rails
- 2 canopy top rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/
California King)
- Screws for attaching
headboard panel
- 4 screws for canopy

Installation Instructions

Note: We recommend assembling this item with a friend. When disassembling, use rubber mallet to remove side rail tab from metal pocket.

1 Hold metal headboard frame upright near its desired placement, with metal pockets facing the center of the bed.

2 With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard. Repeat for other side.

3 Attach footboard to both rails in the same manner as headboard.

4 Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.

5 Place canopy rails with tabs upright on top of bed posts. Push headboard and foot board together.

6 Secure the rails with the screws.

7 To attach headboard panel, face the upholstered side towards the footboard and rest it on the lowest rail, flush with the bars with screw holes.

8 Drill the provided screws into the headboard panel through the screw holes located in the metal headboard frame. See below for required number of screws for each bed size: • Twin bed: three screws per bar (six total) • Full bed: four screws per bar (eight total) • Queen, King, California King bed: five screws per bar (10 total)

9 Place your mattress on the slats.