

CHAPMAN/CORE/FORT/JENNINGS/ LUKA/PARSONS/PIPER BEDS

Recommended Tools/Materials

- Rubber mallet

This Product Includes

- Headboard
- Footboard
- 2 side rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/California King)

Installation Instructions

Note: When disassembling, use rubber mallet to remove side rail tab from metal pocket.

1 Hold headboard upright near its desired placement, with metal pockets facing the center of the bed.

2 With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard. Repeat for other side.

3 Attach footboard to both rails in the same manner as headboard.

4 Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.

5 Place your mattress on the slats.