

AVERY/MARLO/RUE/WYATT BEDS

Recommended Tools/Materials

- Phillips screwdriver and/or drill
- Socket set (½" socket or Ratcheting Wrench ½")

This Product Includes

- Headboard with 6 1-inch hex head bolts (3 on each side)
- Footboard with 6 1-inch hex head bolts (3 on each side)
- 2 side rails with 8 1-inch hex head bolts (4 on each rail)
- Steel support slats
- 4 L-brackets (2 attached to each side rail)

Note: We recommend assembling this item with a friend.

Assembly Instructions

1. Stand the headboard upright. Halfway unscrew the 6 hex head bolts on the headboard (3 on each side) to give enough room to slide the bracket on (see step 2).
2. Slide one side rail up onto the headboard so the L-bracket connects to all 3 bolts. Tighten the 3 hex head bolts onto the L-bracket.
3. Repeat step 2 on the other side of the bed.
4. Keeping the headboard and side rail assembly upright, attach the footboard to the side rails in the same way you attached the headboard.
5. Add the metal slats across the bed with their flat side facing up.
6. Place your mattress on the slats.