

Anti-Tip Safety Hardware for Foshay and Slim Collections

List of parts:

2 brackets (1 extra)
2 1 1/4" screws
2 3/4" screws (extra)
bracket strap

Tools needed:

power drill
3/32" drill bit

Note: This hardware is designed to help prevent furniture from tipping over. Due to the design of this piece, you will use just one of the two included brackets and you will not need the two 3/4" screws.

Directions:

1. Determine desired location of furniture piece. Find wall stud behind furniture piece and position one bracket vertically on the stud approximately 1" below the top of furniture piece. Mark and drill pilot hole in the center of the stud with a 3/32" drill bit. Attach bracket to stud with the two 1 1/4" screws.
2. Move furniture piece into its final position, taking care to line up the wall bracket with furniture. Thread the strap through the bracket and around the furniture as shown in the illustrations. Tighten strap until snug. *Note: Do not overtighten.*

