

Architecture Bed Assembly Instructions

List of parts:

- 1 headboard
- 1 footboard
- 2 side rails
- 2 canopy top rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/California King)
- 4 screws

Tools needed:

- Phillips screwdriver
- rubber mallet

Note: When disassembling, use rubber mallet to remove side rail tab from metal pocket.

Directions:

1. Hold headboard upright near its desired placement, with metal pockets facing the center of the bed.
2. With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard.
Repeat for other side.
3. Attach footboard to both rails in the same manner as headboard.
4. Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.
5. Place canopy rails with tabs upright on top of bed posts. Push headboard and foot board together.
6. Secure rails with screws.
7. Place mattress on slats.

