

### Chilton Bed Assembly Instructions

#### RECOMMENDED TOOLS AND MATERIALS:

- Power drill
- 8 1/4" x 1 1/4" lag screws and 8 1/4" washers
- Clamps (optional)

#### THIS PRODUCT INCLUDES:

- Chilton live edge wood headboard (x1)
- Steel headboard slats (x2)
- Steel footboard (x1)
- Side rails (x2)
- Steel slats (x12)

#### RECOMMENDATIONS:

Assemble this bed with two people

#### Attaching the headboard

- 1 Position Chilton headboard so the live edge is the top of the headboard.
- 2 Align pilot holes on backside of Chilton headboard to holes in steel brackets.
- 3 If possible, clamp Chilton headboard to the brackets to hold in place.
- 4 Pre-drill each attachment point with 3/16" drill bit.
- 5 Attach with eight lag screws and washers. Now this assembly is ready for attachment to the rest of the bed. (Figure 1)

#### Assembling the bed frame

- 1 Hold the now attached Chilton and steel headboard brackets upright near desired placement in room, with metal pockets facing the center of the bed.
- 2 With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard. Repeat for other side.
- 3 Attach footboard to both rails in the same manner as headboard.
- 4 Place steel slats onto the side rails matching the slots in each slat to the rivet on the side rails.
- 5 Place mattress on slats.

Figure 1

