

Copenhagen Bed Assembly Instructions



List of parts:

- 1 headboard
- 2 leg assembly
- 2 side rails
- 10 slats (Full)
- 12 slats (Queen/King)
- 8 9/16" bolts
- 2 brackets

Tools needed:

- 1/4" Allen wrench (provided)
- wrench

Directions:

1. Insert leg assembly into side rail and push until side rail is flush. Repeat on other leg assembly.
2. Using the Allen wrench provided, tighten the four set screws.
3. Place brackets onto headboard. Insert bolts from the back of the headboard: Place the third bolt from the top in each bracket to stabilize the brackets. Install the top two bolts to headboard and tighten.
4. Center headboard onto frame. Insert final two bolts and tighten.
5. Place slats evenly across bed frame.

