

Core Bed Assembly Instructions



List of parts:

- 1 headboard
- 1 footboard
- 2 side rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/California King)

Tools needed:

- rubber mallet

Note: When disassembling, use rubber mallet to remove side rail tab from metal pocket.

Directions:

1. Hold headboard upright near its desired placement, with metal pockets facing the center of the bed.
2. With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard.
Repeat for other side.
3. Attach footboard to both rails in the same manner as headboard.
4. Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.
5. Place mattress on slats.