

LOFT FLOOR MIRROR

Anti-Tip Hardware Installation Instructions

- 1** Place the mirror at your desired location against the wall. With a pencil, make a mark on the wall at the center of the top of the mirror.
- 2** Move the mirror away so you can see the pencil mark. Measure down two inches from the pencil mark and install the provided wall bracket horizontally, so the Clevis pin holes are on the top and bottom of the wall anchor. Use the included screws to install the bracket into a wall stud, or the included drywall anchors to install the bracket into drywall.
- 3** Attach the free end of the cable to the wall bracket with the Clevis pin and hair pin.
- 4** Reposition the mirror in your desired location.