

Manhattan Frame Installation Instructions

List of parts:

Manhattan Frame

Tools needed:

hammer

common nail

Directions:

1. Place the frame face down on a flat, protected surface.
2. Slide the back board from the frame. (Figure 1)
3. Position your image in the mat window opening. *Optional: Secure image with tape to keep it from shifting.*
4. Insert the backing board into the frame.
5. Hammer the nail 3/4 of the way into desired wall location and hang frame so it's flush against the wall, positioning frame on built-in notch for extra stability.



Figure 1