

# Profile Frame Installation Instructions

## List of parts:

Wood Profile Frame  
linen tape (included)

## Tools needed:

flat-blade screwdriver  
hammer  
common nail

## Directions:

1. Place the frame face down on a flat, protected surface.
2. Carefully slide a flat-blade screwdriver under the flexible metal tabs and gently bend them up, toward the edge of the frame. (Figure 1)
3. Remove the backing board from the frame.
4. Position your image in the mat window opening. Secure image to the mat or backing board with the included linen tape to keep it from shifting (optional). Simply peel and stick.
5. Place the backing board in the frame, on top of the mat.
6. Using a flat-blade screwdriver, gently bend the flexible metal tabs back to their original position to secure the glass, mat and backing board in the frame.
7. Hammer the nail 3/4 of the way into desired wall location and hang frame so it's flush against the wall.



Figure 1