

### Architecture Bed with Fabric Headboard

#### RECOMMENDED TOOLS AND MATERIALS:

- Phillips screwdriver
- Rubber mallet

#### THIS PRODUCT INCLUDES:

- 1 headboard
- headboard panel
- 1 footboard
- 2 side rails
- 2 canopy top rails
- 10 slats (Twin/Full)
- 12 slats (Queen/King/California King)
- screws for attaching headboard panel
- 4 screws for canopy

#### NOTE:

When disassembling, use rubber mallet to remove side rail tab from metal pocket.

- 1 Hold metal headboard frame upright near its desired placement, with metal pockets facing the center of the bed.
- 2 With plastic pieces facing the center of the bed, place one side rail tab in the metal pocket of headboard. Repeat for other side.
- 3 Attach footboard to both rails in the same manner as headboard.
- 4 Place slats onto the side rails matching the slots in each slat to the rivet on the side rails.
- 5 Place canopy rails with tabs upright on top of bed posts. Push headboard and footboard together.
- 6 Secure rails with screws.
- 7 To attach headboard panel, face the upholstered side towards the footboard and rest it on the lowest rail, flush with the bars with screw holes.
- 8 Drill the provided screws into the headboard panel through the screw holes located in the metal headboard frame.  
See below for required number of screws for each bed size:
  - Twin bed: three screws per bar (six total)
  - Full bed: four screws per bar (eight total)
  - Queen, King, California King bed: five screws per bar (10 total)
- 9 Place mattress on slats.

