


STUDIO AND LUISA PENDANT

This Product Includes

- A. Wire nuts
- B. Mounting plate
- C. Mounting screws
- D. Canopy
- E. Canopy screws
- F. Wire clamp
- G. Screw
- H. Shade washer
- I. Shade washer
- J. Split washer

ATTENTION

If you do not have an existing electrical light box in your intended installation site, have one installed by a licensed electrician.



ATTENTION

These instructions are provided for your safety. It is very important they are read completely before beginning the installation of your fixture. WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN. Turn off power before replacing bulbs.

Installation Instructions

- 1** Remove Mounting plate (B) from canopy (D) by removing canopy screws (E). Set canopy screws aside.
- 2** Affix mounting plate (B) to ceiling outlet box with mounting screws (C).
- 3** Measure desired drop for fixture to hang.
- 4** From inside canopy (D), loosen screw (G) on wire clamp (F) and tighten screw (G). If necessary, cut cord, leaving 5-6 inches of length for wire connections.
- 5** Using the included wire nuts, twist together the wires from the pendant with their corresponding wires from the junction box. Tuck the excess wire up into the junction box.
- 6** Place canopy (D) flush against ceiling and use canopy screws (E) to attach the canopy to the mounting plate. Place bulbs in socket.
- 7** Lift shade over the bottom section of fixture. Slide the split washer (J) between shade washer (H) and shade washer (I). Secure the shade by turning shade washer (H) clockwise until it rests firmly against split washer (J).