

Agenda Magnetic Board Installation Instructions

List of parts:

Agenda Magnetic Board
wall anchors
skrews



Tools needed:

#2 Phillips screwdriver
pencil
power drill
level (optional)

Note: Maximum recommended load is 20 pounds

Directions:

1. Mark desired hole location on wall with pencil then drill hole locations.
2. Use a #2 Philips screwdriver to install the wall anchors at hole locations.
3. Place fixture over wall anchor and insert screw with #2 Phillips screwdriver.
4. Tighten Agenda Magnetic Board into place.

Note: Screw self-threads into anchor. Do not overtighten.

