

CEDRIC FLOOR LAMP





THIS PRODUCT INCLUDES:













(bulb not to scale)

A. Cedric lamp base

- B. Upper lamp shade
- C. Lower lamp shade
- D. Dimmable LED light bulb (x2)



Screw in both LED light bulbs before attaching the lamp shades.


Caution: take care not to bend the shades during assembly.



Place the upper shade onto the top of the lamp body and the lower shade onto the bottom of the lamp body. The shades magnetically attach. Twist each shade so that the vertical seam in the fabric is located at the back of the lamp.



There are six adjustable magnetic pins in the lamp body. If the shades are uneven after installation, remove the shades and twist the magnetic pins in or out to adjust the alignment so each shade is perfectly level.



SPECIAL CONSIDERATIONS

Not all light bulbs are dimmable. Order replacement bulbs at roomandboard.com.

