


# Room&Board

## INSTALLATION INSTRUCTIONS

Keep these instructions for future use

## ORIKATA FLUSHMOUNT 28" PENDANT




### CAUTION


- It is strongly recommended that the hardwire installation of this product is done by a professional.
- Read these safety instructions entirely prior to installation.
- **DO NOT BEGIN INSTALLATION UNTIL ALL ELECTRICAL POWER TO THE INSTALLATION SITE HAS BEEN TURNED OFF AT THE CIRCUIT BREAKER!**

### Recommended Tools and Materials

- Screwdriver
- Wire cutter



### This Product Includes



A. Orikata shade




C. Mounting screws (2)




D. Wire nuts (2)

**CAUTION:** Use an LED lightbulb (*not included*) to avoid product damage. Recommended bulbs can be purchased on roomandboard.com


1. Turn off power to the circuit at the breaker.
2. Using wire cutters/strippers, trim back about 3/4" of insulation from the two wires connected to the mount socket.
3. Cap the bare ground wire with a wire nut (if your fixture doesn't use a ground).




4. Connect the mounting plate wires to the junction box wires with the provided wire nuts (typically black-to-black/hot, white-to-white/neutral).
5. Attach the mounting plate to the junction box using the two mounting screws.



6. Align the shade on the mounting plate and rotate slowly with light upward pressure until the magnets engage.



7. With power still OFF, spread the pendant open along its vertical seam to expose the socket and install the bulbs. Close the seam.



8. Restore power at the breaker and test the light.

**Safety tip: If you're unsure about any step, hire a licensed electrician.**