


PARSONS HEIGHT-ADJUSTABLE DESK



Recommended Tools and Materials

- Phillips head screwdriver

This Product Includes


A. top frame with control box

C. Allen bolts

E. return kit (included with desks
with returns)


B. legs

D. controller & mounting bracket



Installation Instructions


- 1 Using the included Allen key, attach all legs to the top frame, ensuring the mounting plate is oriented so the cord exits through the square notch.



- 2 Connect the leg cables to the top frame cables.

- 3 Connect the height controller and its mounting bracket to the control box.


- 4 Route cables through the top frame to the control box and connect them to their respective ports.



Installation Instructions: Adding the Return

Note: The height controller may need to be relocated to place the return. It can be moved to several locations along the underside of the desk top frame or the return top frame.

- 1 If your desk includes a return, use the included Phillips head bolts and a Phillips head screwdriver to attach the return connector plate to the desk. Partially thread the Phillips head bolt into the desired mounting location on the Parsons desk. Slide the connector plate between the frame and then head of the bolt, then tighten it.



- 2 Connect cords, run through frame, plug into control box. (See earlier instructions.)

