


ALTA WALL SHELF



RECOMMENDED TOOLS AND MATERIALS:



Pencil
1/16" drill bit

#2 Phillips screwdriver
Power drill




Tape measure
Level

THIS PRODUCT INCLUDES:

- A. - Drywall anchors (X4)
- B. - Mounting screws (X4)
- C. - Assembly screws (X8)
- D. - Washer (X4)
- E. - Top shelf
- F. - Steel frame
- G. - Bottom shelf




(hardware not to scale)



G.

1

Begin by fastening the top shelf to the steel frame using four of the included assembly screws. Next fasten the bottom shelf to the steel frame with the four remaining assembly screws.




2

Determine the mounting location of your wall shelf by holding it in place against the wall. Use a level to ensure it is straight. Then, use a pencil to mark the placement of four screws through the slotted holes in the back of the steel frame (one in each slot).

3

Set the shelf aside and use a power drill and 1/16" drill bit to drill pilot holes into the drywall. Use a screwdriver to drive the drywall anchors into the pilot holes until they are flush with the wall.

Note: For added strength, mount the wall shelf to an existing stud. Slots in the back of the steel frame are designed to allow proper positioning over a stud. Wall anchors are not necessary for stud mounting.



4

Align the slots in the back of the steel frame with the wall anchors and use the included mounting screws and washers to fasten the unit to the wall.

SPECIAL CONSIDERATIONS:

Alternative hardware may be required when mounting to a surface other than drywall. Consult a professional if you have any questions regarding proper installation.